



Electrolux

Instruction Book

使用説明手冊

사용 설명서

Sách Hướng Dẫn


Buku Petunjuk


คู่มือการใช้งาน





کتاب التعليمات







600 CORDLESS CLEANER




EFP61712A / EFP61713A / EFP61712 /
EFP61714 / EFP61713









































 www.shop.electrolux.com



ESKW6	ZE195	ZE189	EPPCS2	ZE187	ZE158	ZE159
900 923 742	900 923 813	900 923 803	900 923 550	900 923 769	900 923 440	900 923 442
Yearly Performance Kit	Extra Battery 2.5Ah/54Wh	Extra Battery Taiwan / Japan 2.5Ah/54Wh	PowerPro Cleaning Station	PowerPro Mop Nozzle	Standard Pads	Delicate Pads

*Accessories are subject to country availability.

A27940403