



# Electrolux

Instruction Book

使用説明手冊

사용 설명서

Sách Hướng Dẫn

Buku Petunjuk

คู่มือการใช้งาน

کتاب التعليمات


## 800 CORDLESS CLEANER
















EFP81812W/EFP81813B/EFP81814

EFP81824/EFP81825A/EFP81825/

EFP81812S/EFP81824S/EFP81825SB/

EFP81835S





\*

Available in specific models only.

只適用於指定型號

특정 모델에만 해당 됩니다.

Chỉ có ở một số kiểu máy nhất định.

Tersedia hanya pada model tertentu.

มีเฉพาะบางรุ่นเท่านั้น








متوفر في نماذج محددة فقط












Carpet






















Hard Floor
































[www.shop.electrolux.com](http://www.shop.electrolux.com)



**ESKW6**

900 923 742

**Yearly  
Performance Kit**



**ZE155**

900 923 379


**PetPro+**



**ZE149**

900 923 380


**BedProPower+**



**ZE149A**

900 923 381

**BedProPowerUV+**



**ZE190**

900 923 812


**Extra Battery  
4.0Ah/100Wh**



**EPPCS2**

900 923 550


**PowerPro  
Cleaning Station**



**E201S**

900 168 458


**S-bag for  
Emptying Station**



**ZE177**

900 923 744


**PowerPro  
Mop+ Nozzle**



**ZE158**

900 923 440

**Standard Pads**



**ZE159**

900 923 442

**Delicate Pads**

\*Accessories are subject to country availability.

